

Refers to: Ignition signal incorrect connection

In TECH controllers, especially in TECH ONE, "+ ignition" must not be connected to ignition coil signal wire. Incorrect connection may cause damage of electronic components and loss of producer warranty.

When LPGTECH service identify that damages were caused by incorrect connection all complaints will not be considered.

Please note that the correct assembly is shown on wiring diagrams included in each installation kit. Additional information can be found in the "Installing electric. autogas systems - TECH_v.02" video, in part relating to connecting cables - ignition and coil plug.

If you have further questions, please contact our **Technical Support:**

e-mail: help@lpgtech.pl

tel.: +48 85 734 13 58
mob.: +48 502 447 473
+48 502 447 470